

HABOTEST®

**HT113 Series
Handheld 600V
Digital Multimeter**





HT113

Manual Range
Basic

HT113A

Manual Range
Standard

HT113B

Auto Range
Standard TRMS

HT113C

Auto Range
Advance TRMS



Functions	HT113	HT113A	HT113B	HT113C
AC Voltage	0~600V	0~600V	0~600V	0~600V
DC Voltage	0~600V	0~600V	0~600V	0~600V
AC Current	-	0~10A	0~10A	0~10A
DC Current	0~10A	0~10A	0~10A	0~10A
Resistance	0~20M Ω	0~20M Ω	0~40M Ω	0~60M Ω
Diode Test	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Continuity	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Auto Off	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Data Hold	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Backlight	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
NCV Detection		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Live Wire Test				<input checked="" type="checkbox"/>
Flashlight		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Frequency			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Max			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
True RMS			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Capacitance				<input checked="" type="checkbox"/>
Battery Test	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	